

TWILIGHT VARIATIONS

Select your style choices for Cover (A) - Shape (F) - Height (G) - Panel (H) - Border (J)

Step 1: Choose your Shape (F)

F1 straight F2 crescent F3 elegant F4 camel

Step 2: Choose your Height (G)

G1 standard 56" G2 tall 63" G3 grande 70"

Step 3: Choose your Panel (H)

H1 plain H2 square button tufted H3 square button less tufted H4 diamond button tufted

Step 4: Choose your Border (J)

J1 borderless J2 borderless & small nailheads

J3 borderless & large nailheads J4 double welt

J5 welt edge & small nailheads J6 double row nailheads

